

**FIRST FILL FABRIC CLEANER** is a powerful cleaner and degreaser for thorough cleaning of clothing, upholstery and furniture. Suitable for removing all kinds of pollution such as dirt residue from mineral, vegetable and animal oils, nicotine deposits, greasy surfaces, etc.

Fabric Cleaner emulsifies the pollution and even penetrates deep into the material.

#### APPLICATION

For the cleaning of furniture, clothing, rugs, upholstery and other materials. Suitable for any type of fabric and material.

#### PROPERTIES

- Free from hazard symbols
- Fully biodegradable
- Excellent cleaning and degreasing
- Ready to use
- Non-corrosive
- Environment and material friendly
- Non-flammable
- Multifunctional applicable

#### INSTRUCTIONS

Apply Fabric Cleaner on the surface by spraying or brushing. Let it soak in for a couple of minutes and pat dry with a clean cloth or sponge. If necessary, wipe the surface with a wet sponge and/or cloth before patting it dry. Repeat proces if necessary.

#### PHYSICAL PROPERTIES

Color	:	Transparent
Components	:	Water, surfactants
Density	:	± 0,98 kg/l
pH-value	:	7



#### PACKAGING OPTIONS

- 200 ml Airopack®
- 5 / 10 / 25 LTR Cans
- 210 LTR Drums
- 1.000 LTR IBC

SCAN QR-CODE  
FOR MORE INFORMATION



By product choice always follow the requirements and instructions of the manufacturer.